


Articulator Support Leg Instructions

Item #AR300000

1




Place the support leg under the lower frame at rear, making sure the support leg lip "grabs" the lower frame

2



Raise the support leg up to secure the lower lip of the support leg against the articulator frame

3



Release hand pressure on the support leg. It should now be attached to the articulator frame.

4



Articulator with the support leg installed in an upright position

5



Articulator tilted at 45° angle with the support leg installed.